



Helipad™ INSTALLATION DATA SHEET

The ready to use Helipad™ kit consists in :

Two or three rolls with selvage to avoid fraying, equipped on the edges with reinforced stainless steel eyelets, and one or several bags containing set up accessories and tools.

The Helipad™ light weight makes it easy to install manually and to transport by air to optimize operations.

1. Pre-installation

Open the wood/carton box containing the Helipad™ rolls, and take the rolls. Simply lift each roll and carry them all to the spot of use (Picture 1).

2. Ground preparation

Level the ground and rake to remove sharp stones and pebbles that might hinder installation.

The Helipad™ is flexible and without sewing, it fits perfectly all types of ground.

Option :

If you wish to prevent the grass from growing through the mat, it is recommended to lay the Helipad™ on a non woven geotextile undermat.

3. Place the rolls Helipad™

The stakes, tools and gloves are delivered in a bag (Picture 2).

Use the gloves to unroll the Helipad™ (Picture 3).

Use the handling hooks to position the mat on the ground and avoid waves.

4. Anchor and stretch the Helipad™

Anchor one end with the stakes and insert them into the eyelets (Picture 4).

Stretch the mat using the handling hooks supplied with the kit before securing the opposite end with stakes through eyelets (Picture 5).

Stretch the mat to avoid waves.

Anchor the opposite end with the stakes and insert them into the eyelets.



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Usine de Bourisson BP 40020 - 16400 La Couronne - France
Tél. + 33 (0) 545 677 030 - Fax. + 33 (0) 545 678 160

deschamps@deschamps.fr